



FIXING INSTRUCTIONS – LOCKCASE SERIES 4000

Fixing Instructions

- Fold the template along dotted line A and place at leading edge of door as shown in fig. 1.
- Mark the centres of the handle turn hole B and the cylinder hole C. Drill two $\phi 25$ mm holes through the door. Mortice for full depth of lockcase and cut 3 mm depth for faceplate.
- Push the lockcase into the cut-out without using force and screw through forend with the supplied screws.
- For precisely drilling of the holes ($\phi 7$ mm) for rose and escutcheon, (Glutz 5620, 5380 WC) use site fixing template No. 203. Without the template No. 203 the position is marked as (X) for through drilling

